



Duraliner® Bedliners														
TRUCK MODEL	YEAR	SIZE	UNDER RAIL					OVER RAIL						
			Group Part Number	Liner	Tailgate Cover	Install Kit	Added Features	Group Part Number	Liner	Tailgate Cover	Install Kit	Added Features		
<b>CHEVROLET/GMC</b>														
Fleetside / Wideside	1973-87	8' 0"	0052095X	0052095	FC7-BT	PA05120					0012040X	0012040	FC7-BT	PA05015
Fleetside / Wideside	1973-87	6' 6"	0052090X	0052090	FC7-BT	PA05120								
CK Series / Sierra	1988-98	8' 0"	0052080X	0052080	C74-BT	PA05180	1,5,6,7,10				0010098X	0010098	C74-BT	PA05000 6,7
CK Series / Sierra	1988-98	6' 6"	0050003X	0050003	C74-BT	PA05180	1,5,6,7,10				0010102X	0010102	C74-BT	PA05000 6,7
CK Stepside	1988-98	6' 6"	0052085X	0052085	C24-BT	PA05090	6,7,10				0010110X	0010110	C24-BT	PA05050 6,7
Silverado / Sierra	1999-06	8' 0"	0050390X	0050390	C84-BT	PA05195	1,3,5,6,7,9,10				0010390X	0010390	C84-BT	PA05005 3,6,7,8,9
Silverado / Sierra	1999-06	6' 6"	0050389X	0050389	C84-BT	PA05195	1,3,5,6,7,9,10				0010389X	0010389	C84-BT	PA05005 3,6,7,8,9
Silverado Sportside	1999-06	6' 6"	0050391X	0050391	C54-BT	PA05045	1,3,5,6,7,9,10							
Silverado Crew Cab	2004-06	5' 6"	0050544X	0050544	C84-BT	PA05195	1,3,5,6,7,9,10							
Silverado / Sierra Classic Edition	2007	8' 0"	0050390X	0050390	C84-BT	PA05195	1,3,5,6,7,9,10				0010390X	0010390	C84-BT	PA05005 3,6,7,8,9
Silverado / Sierra Classic Edition	2007	6' 6"	0050389X	0050389	C84-BT	PA05195	1,3,5,6,7,9,10				0010389X	0010389	C84-BT	PA05005 3,6,7,8,9
Silverado Crew Cab Classic Edition	2007	5' 6"	0050544X	0050544	C84-BT	PA05195	1,3,5,6,7,9,10							
Silverado	2007-12	8' 0"	0051008X	0051008	C86-BT	PA05282	1,3,5,6,7,9,10				0012056X	0012056	C86-BT	PA05000
Silverado	2007-12	6' 6"	0051007X	0051007	C86-BT	PA05282	1,3,5,6,7,9,10				0012060X	0012060	C86-BT	PA05000 3,6,7
Silverado	2007-12	5' 8"	0051006X	0051006	C86-BT	PA05282	1,3,5,6,7,9,10				0012065X	0012065	C86-BT	PA05000 3,6,7
Sierra	2007-12	8' 0"	0051008X	0051008	C86-BT	PA05282	1,3,5,6,7,9,10				0012052X	0012052	C86-BT	PA05000
Sierra	2007-12	6' 6"	0051007X	0051007	C86-BT	PA05282	1,3,5,6,7,9,10				0012050X	0012050	C86-BT	PA05000 3,6,7
Sierra	2007-12	5' 8"	0051006X	0051006	C86-BT	PA05282	1,3,5,6,7,9,10				0012055X	0012055	C86-BT	PA05000 3,6,7
Silverado / Sierra w/cargo mgt	2007-12	8' 0"	0052115X	0052115	C86-BT	PA05282	1,3,5,6,7,9							
Silverado / Sierra w/cargo mgt	2007-12	6' 6"	0052105X	0052105	C86-BT	PA05282	1,3,5,6,7,9							
Silverado / Sierra w/cargo mgt	2007-12	5' 8"	0052110X	0052110	C86-BT	PA05282	1,3,5,6,7,9							
S-10 / S-15	1982-93	6' 0"	0052100X	0052100	S64-BT	PA05180	3							
S-10 / S-15	1994-03	7' 0"									0012045X	0012045	S62-BT	PA05000 3,6,7
S-10 / S-15	1994-03	6' 0"	0052005X	0052005	S62-BT	PA05180	1,3,5,6,7,10				0012005X	0012005	S62-BT	PA05000 3,6,7
S-10 Sportside	1997-03	6' 0"	0052020X	0052020	S66-BT	PA05180	1,3,5,6,7,10							
Colorado / Canyon	2004-12	6' 0"	0050540X	0050540	S80-BT	PA05200	1,3,5,6,7,10				0010540X	0010540	S80-BT	PA05070 3,6,7
Colorado / Canyon Double Cab	2004-12	5' 0"	0050541X	0050541	S80-BT	PA05200	1,2,5,6,7,10				0010541X	0010541	S80-BT	PA05070 2,6,7
<b>DODGE</b>														
Ram T300 (Ram 1500)	1994-01	8' 0"	0052015X	0052015	D72-BT	PA05120	1,3,5,6,7,10				0012020X	0012020	D72-BT	PA05015 3,7
Ram T300 (Ram 1500)	1994-01	6' 6"	0052010X	0052010	D72-BT	PA05120	1,3,5,6,7,10				0012015X	0012015	D72-BT	PA05015 3,7
Ram T300 (2500 & 3500)	1994-02	8' 0"	0052015X	0052015	D72-BT	PA05120	1,3,5,6,7,10				0012020X	0012020	D72-BT	PA05015 3,7
Ram T300 (2500 & 3500)	1994-02	6' 6"	0052010X	0052010	D72-BT	PA05120	1,3,5,6,7,10				0012015X	0012015	D72-BT	PA05015 3,7
Ram DR -- 1500 Series	2002-08	8' 0"	0050575X	0050575	D92-BT	PA05125	1,3,5,6,7,8,9,10				0010522X	0010522	D92-BT	PA05025 3,7,8,9
Ram DR -- 1500 Series	2002-08	6' 4"	0050576X	0050576	D92-BT	PA05125	1,3,5,6,7,8,9,10				0010586X	0010586	D92-BT	PA05025 3,7,8,9
Ram DR -- 2500 / 3500 Series	2003-09	8' 0"	0050575X	0050575	D90-BT	PA05125	1,3,5,6,7,8,10				0010522X	0010522	D90-BT	PA05025 3,7,8
Ram DR -- 2500 / 3500 Series	2003-09	6' 4"	0050576X	0050576	D90-BT	PA05125	1,3,5,6,7,8,10				0010586X	0010586	D90-BT	PA05025 3,7,8
Ram DS -- 1500 Series	2009-12	8' 0"	0050575ZXX	0050575	D96-BT	PA05125	1,3,5,6,7,8,9,10							
Ram DS -- 1500 Series	2009-12	6' 4"	0050576ZXX	0050576	D96-BT	PA05125	1,3,5,6,7,8,9,10							
Ram DS -- 1500 Series	2009-12	5' 7"	0052000X	0052000	D96-BT	PA05125	1,3,5,6,7,8,9,10							
Ram DS -- 2500 / 3500 Series	2010-12	8' 0"	0050575ZXX	0050575	D96-BT	PA05125	1,3,5,6,7,8,9,10							
Ram DS -- 2500 / 3500 Series	2010-12	6' 4"	0050576ZXX	0050576	D96-BT	PA05125	1,3,5,6,7,8,9,10							
Ram DS -- 1500 Series RamBox	2012	6' 4"	0052191X	0052190	D95-BT	PA01059	3,7,9,10							
Ram DS -- 1500 Series RamBox	2009-12	5' 7"	0052190X	0052190	D95-BT	PA01059	3,7,9,10							
Dakota	1986-96	6' 6"	0050206X	0050206	D60-BT	PA05120	1,5,6							
Dakota	1997	6' 6"	0050206X	0050206	D62-BT	PA05120	1,3,5,6,7				0010598X	0010598	D62-BT	PA05015 3,7
Dakota	1998-04	6' 6"	0050374X	0050374	D62-BT	PA05120	1,3,5,6,7,10				0010374X	0010374	D62-BT	PA05015 3,7
Dakota Quad Cab	2000-04	5' 6"	0050559X	0050559	D62-BT	PA05135	1,3,5,6,7,8,10				0012070X	0012070	D62-BT	PA05015 7
Dakota	2005-07	6' 6"	0050374X	0050374	D58-BT	PA05120	1,3,5,6,7,10				0010558X	0010558	D58-BT	PA05015 7
Dakota Quad Cab	2005-07	5' 6"	0050559ZXX	0050559	D58-BT	PA05135	1,3,5,6,7,8,10				0010557X	0010557	D58-BT	PA05015 7
Dakota w/o spoiler	2007-5-11	6' 6"	0050586X	0050586	D58-BT	PA05001	1,3,5,6,7,8,10				0010559X	0010559	D58-BT	PA05015 3,6,7
Dakota Quad Cab w/o spoiler	2007-5-11	5' 6"	0050585X	0050585	D58-BT	PA05002	1,3,5,6,7,10				0010560X	0010560	D58-BT	PA05015 3,6,7
Dakota w/spoiler	2008-11	6' 6"	0050586ZXX	0050586	D78-BT	PA05001	1,3,5,6,7,8,9,10							
Dakota Quad Cab w/spoiler	2008-11	5' 6"	0050585ZXX	0050585	D78-BT	PA05002	1,3,5,6,7,9,10							
<b>FORD</b>														
Styleside Series	1975-86	8' 0"	0052065X	0052065	FC7-BT	PA05120	1,5,6				0012035X	0012035	FC7-BT	PA05015 6
Styleside Series	1975-86	7' 0"	0052070X	0052070	FC7-BT	PA05120	1,5,6				0012030X	0012030	FC7-BT	PA05015 6
Styleside Series	1987-96	8' 0"	0052065ZXX	0052065	F74-BT	PA05140	1,5,6				0012035ZXX	0012035	F74-BT	PA05030 6
Styleside Series	1987-96	7' 0"	0052070ZXX	0052070	F74-BT	PA05140	1,5,6				0012030ZXX	0012030	F74-BT	PA05030 6
F-150	1997-03	8' 0"	0050274X	0050274	F76-BT	PA05175	1,3,5,6,7,8,9,10							
F-150	1997-03	6' 6"	0050275X	0050275	F76-BT	PA05175	1,3,5,6,7,8,9,10							
F-150 Super Crew	2000-03	5' 6"	0050436X	0050436	F82-BT	PA05165	1,3,5,6,7,8,9,10							
F-150 Flareside	1997-03	6' 6"	0050276X	0050276	F82-BT	PA05175	1,3,5,6,7,8,9							
F-150 Heritage Edition	2004	8' 0"	0050274X	0050274	F76-BT	PA05175	1,3,5,6,7,8,9,10							
F-150 Heritage Edition	2004	6' 6"	0050275X	0050275	F76-BT	PA05175	1,3,5,6,7,8,9,10							
F-150 Flareside Heritage Edition	2004	6' 6"	0050276X	0050276	F82-BT	PA05175	1,3,5,6,7,8,9							
F-150 Flareside	2004-09	6' 6"	0052040X	0052040	F86-BT	PA05175	1,3,5,7,8,9,10							
F-150 w/out cargo mgt	2004-12	8' 0"	0050533ZXX	0050533	F90-BT	PA05175	1,3,5,6,7,8,9,10							
F-150 w/out cargo mgt	2004-12	6' 6"	0050532ZXX	0050532	F90-BT	PA05175	1,3,5,6,7,8,9,10							
F-150 Super Crew w/out cargo mgt	2004-12	5' 6"	0050531ZXX	0050531	F90-BT	PA05140	1,3,5,6,7,9,10							
F-250	1997-98	8' 0"	0050274X	0050274	F76-BT	PA05175	1,3,5,6,7,8,9,10							
F-250	1997-98	6' 6"	0050275X	0050275	F76-BT	PA05175	1,3,5,6,7,8,9,10							
F-250 / F-350 / F-450	1999-12	8' 0"	0050343X	0050343	F76-BT	PA05140	1,3,5,6,7,9,10							
F-250 / F-350 / F-450	1999-12	7' 0"	0050345X	0050345	F76-BT	PA05140	1,3,5,6,7,9,10							
F-250 / F-350 w/bed extender	2008-12	8' 0"	0050343ZXX	0050343	F80-BT	PA05140	1,3,5,6,7,9,10							
F-250 / F-350 w/bed extender	2008-12	7' 0"	0050345ZXX	0050345	F80-BT	PA05140	1,3,5,6,7,9,10							
Ranger	1982-92	6' 0"	0052050X	0052050	R60-BT	PA05120	1,5,6,7,10				0012025X	0012025	R60-BT	PA05015 6



<b>Duraliner® Bedliners</b>												
TRUCK MODEL	YEAR	SIZE	UNDER RAIL					OVER RAIL				
			Group Part Number	Liner	Tailgate Cover	Install Kit	Added Features	Group Part Number	Liner	Tailgate Cover	Install Kit	Added Features
<b>ISUZU</b>												
Hombre	1996-03	6' 0"	0052005X	0052005	S62-BT	PA05180	1,3,5,6,7,10	0012005X	0012005	S62-BT	PA05000	3,6,7
I-280 / I-290	2006-08	6' 0"	0050540X	0050540	S80-BT	PA05200	1,3,5,6,7,10	0010540X	0010540	S80-BT	PA05070	3,6,7
I-350 Double Cab	2006-08	5' 0"	0050541X	0050541	S80-BT	PA05200	1,2,5,6,7,10	0010541X	0010541	S80-BT	PA05070	2,6,7
<b>MAZDA</b>												
B-Series	1994-97	7' 0"						0010283X	0010283	R28-BT	PA05030	6,7
B-Series	1994-97	6' 0"	0052050Z	0052050	R28-BT	PA05055	1,5,6,7,10	0010185X	0010185	R28-BT	PA05030	6,7
B-Series w/ Tie Downs	1997	6' 0"	0050293X	0050293	R28-BT	PA05140	1,3,5,6,7,10	0010282X	0010282	R28-BT	PA05030	3,6,7
B-Series	1998-10	6' 0"	0050293X	0050293	R28-BT	PA05140	1,3,5,6,7,10					
<b>MITSUBISHI</b>												
Raider Club Cab	2006-07	6' 6"	0050374Z	0050374	D58-BT	PA05120	1,3,5,6,7,10	0010558X	0010558	D58-BT	PA05015	7
Raider Quad Cab	2006-07	5' 6"	0050559Z	0050559	D58-BT	PA05135	1,3,5,6,7,8,10	0010557X	0010557	D58-BT	PA05015	7
Raider Club Cab w/o Spoiler	2008-09	6' 6"	0050586X	0050586	D58-BT	PA05001	1,3,5,6,7,8,10					
Raider Quad Cab w/o Spoiler	2008-09	5' 6"	0050585X	0050585	D58-BT	PA05002	1,3,5,6,7,10					
<b>NISSAN</b>												
Titan King Cab	2004-12	6' 6"	0050535X	0050535	N10-BT	PA05055	1,3,5,10					
Titan Crew Cab	2004-12	5' 6"	0050536X	0050536	N10-BT	PA05055	1,3,5,6,10					
Hardbody / Frontier King Cab	1986-93	6' 0"						0010409X	0010409	N36-BT	PA05035	
Hardbody / Frontier	1986-97	6' 0"						0012195X	0012195	N36-BT	PA05035	3
Hardbody / Frontier King Cab	1994-00	6' 0"	0052125X	0052125	N36-BT	PA05220	1,3,5,6,10	0010409X	0010409	N36-BT	PA05035	
Frontier	1998-00	6' 4"						0012190X	0012190	N36-BT	PA05035	3
Hardbody / Frontier King Cab	2001-04	6' 0"	0052125Z	0052125	N30-BT	PA05220	1,3,5,6,10	0010409Z	0010409	N30-BT	PA05035	
Frontier	2001-04	6' 4"						0012190Z	0012190	N30-BT	PA05035	3
Frontier King Cab (Suzuki 09-11)	2005-12	6' 0"	0050548X	0050548	N20-BT	PA01108	3,9,10					
Frontier Crew Cab (Suzuki 09-11)	2005-12	5' 0"	0052120X	0052120	N20-BT	PA01108	3,9,10					
<b>TOYOTA</b>												
Tundra	1999-00	8' 0"	0050484X	0050484	T76-BT	PA05085	1,3,5,6,7,10	0012185X	0012185	T76-BT	PA05030	3,6,7
Tundra	1999-00	6' 2"	0050432X	0050432	T76-BT	PA05085	1,3,5,6,7,10					
Tundra	2001-06	8' 0"	0050484Z	0050484	T78-BT	PA05085	1,3,5,6,7,9,10	0012185Z	0012185	T78-BT	PA05030	3,6,7,9
Tundra - Not 4 Doors	2001-06	6' 2"	0050432Z	0050432	T78-BT	PA05085	1,3,5,6,7,9,10					
Tundra Crew Cab - 4 Full Doors	2004-06	6' 0"	0050542X	0050542	T90-BT	PA05055	1,3,5,6,7,9,10					
Tundra	2007-12	8' 0"	0050570X	0050570	T84-BT	PA05286	1,3,5,6,9,10					
Tundra	2007-12	6' 6"	0050569X	0050569	T82-BT	PA05286	1,3,5,6,7,9,10					
Tundra	2007-12	5' 6"	0050568X	0050568	T82-BT	PA05286	1,3,5,6,7,9,10					
Tundra w/cargo mgt	2007-12	8' 0"	0052145X	0052145	T84-BT	PA05286	1,3,5,6,9					
Tundra w/cargo mgt	2007-12	6' 6"	0052135X	0052135	T82-BT	PA05286	1,3,5,6,7,9					
Tundra w/cargo mgt	2007-12	5' 6"	0052140X	0052140	T82-BT	PA05286	1,3,5,6,7,9					
Downsize	1989-95	6' 0"						0012180X	0012180	T38-BT	PA05030	3,6,7
Tacoma	1995-04	6' 0"	0050267X	0050267	T38-BT	PA05085	3,6,7,10	0012200X	0012200	T38-BT	PA05030	3,6,7
Tacoma Double Cab	2001-04	5' 0"	0050500X	0050500	T38-BT	PA05085	3,6,7,10					

ADDED FEATURE KEY	
1 = Horizontal Board Holders	6 = Vertical Board Holder Slots
2 = Rear Tie-Down Cutouts Only	7 = Cup Holders
3 = Front & Rear Tie-Down Cutouts	8 = Tie Down Plugs included in Kit
	9 = Tailgate has No Lip
5 = Pocket Detents	10 = Cab End of Bedliner has Lip



2344 W. Wisconsin St., Portage, WI 53901  
(608) 742-5301